Replacing a backsplash mounted fixture?...

FISHER makes it **EZ!**




1 REMOVE existing plumbing fixture. Be sure to KEEP existing hardware connection attached to backsplash. Insert washers and Fisher EZ Install Adapter.



2 ATTACH new FISHER backsplash mount control body to EZ Install Adapter.



3 CONNECT swing spout or pre-rinse components. TIGHTEN all fittings. It's that EZ!



With the FISHER EZ Install Adapter, there's **NO NEED** for a plumber to remove the stainless steel sink for access... saving you time and money!

The EZ Install Adapter allows for a quick upgrade to any quality FISHER backsplash mount faucet or pre-rinse system. Select from a wide choice of styles designed for the rigors of commercial foodservice use.

It's EZ as 1... 2... 3!

